AD0104081C3

Service Manual

Amplifier

SE-HD550

Colour

(N).....Gold Type

Area

(GN).....Oceania.



SPECIFICATIONS

Because of unique interconnecting cables, when a component requires service, send or bring in the entire system.

System	SC-HD550
Tuner	ST-HD550
Amplifier	**SE-HD550**
CD Player	SL-HD550
Cassette Deck	RS-HD550
Speakers*	SB-HD550

*: Made in Spain.

Specifications

Amplifier section (Low frequency)

Power output:	
DIN 1 kHz, THD 1 %,	
both channels driven;	2×11 W (6 Ω)
RMS 1 kHz, THD 10 %,	
both channels driven;	2×15 W (6 Ω)
Total harmonic distortion:	
Half power at 1 kHz;	0.07 % (6 Ω)
Load impedance:	6 Ω

Amplifier section (High frequency)

Power output:	
DIN 10 kHz, THD 1 %,	
both channels driven;	2×7 W (6 Ω)
RMS 10 kHz, THD 10 %,	
both channels driven;	2×10 W (6 Ω)
Load impedance:	6 Ω
S/N:	78 dB
Rated power, 2 V input, VGCA ON;	98 dB

Headphones

Jack type:	3.5 mm STEREO
Load impedance:	16 – 32 Ω

General

Power supply:	AC 230 – 240 V, 50 Hz
Power consumption:	79 W
STANDBY condition:	0.9 W
Dimensions (W×H×D):	210×104.8×273 mm
Mass:	3.3 kg

Notes: Specifications are subject to change without notice.
Mass and dimensions are approximate.
Total harmonic distortion is measured by the digital spectrum analyzer.

© 2001 Matsushita Electric Industrial Co., Ltd. All rights reserved.
Unauthorized copying and distribution is a violation of law.

⚠ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public.
It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product.
Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

Technics®

1. Before Repair

1. Turn off the power supply. Using a 10 Ω, 10 W resistor, connect both ends of power supply capacitors (C601, C602) in order to discharge the voltage.
2. Before turning the power supply on, after completion of repair, slowly apply the primary voltage by using a power supply voltage controller to make sure that the consumed current at 50 Hz in NO SIGNAL mode should be shown below with respectto supply voltage 240 V.

Power supply voltage	AC 240 V
Consumed current 50 Hz	50 - 180 mA

2. Protection Circuitry

The protection circuitry may have operated if either of the following conditions is noticed:

- No sound is heard when the power is supplied.

- Sound stops during a performance.

The functions of this circuitry is to prevent circuitry damage if, for example, the positive and negative speaker connection wires are shorted, or if speaker systems with an impedance less than the indicated rated impedance of this unit are used.
If this occurs, follow the procedure outlined bellow:

1. Press the Standby/on button, switch to standby mode.
2. Determine the cause of the problem and correct it.
3. Press the Standby/on button once again, supply the power.

Note:

When the protection circuitry functions, the unit will not operate unless the Standby/on button is first switched Standby and then ON again.

3. Accessories

- AC power supply cord
(RJA0035-X).....1 pc.



- AM loop antenna set
(RSA0033B).....1 pc.



- FM indoor antenna
(RSA0006-J).....1 pc.



- Speaker cords
(REE1057) (Red, Black).....2 pcs.
(REE0853) (Blue, Gray).....2 pcs.

- Remote control transmitter
(EUR7702010).....1 pc.



- Remote control batteries
(R6/LR6, AA, UM-3).....2 pcs.
Note: These are available on sales route.



4. Location of Controls

5. Operation Checks and Component Replacement / Procedures

- This section describes procedures for checking the operation of the major printed circuit boards and replacing the main components.
- For reassembly after operation checks or replacement, reverse the respective procedures. Special reassembly procedures are described only when required.

5.1. Checking for the power supply P.C.B.



- Check the power supply P.C.B. as shown below.



5.2. Checking for the operation P.C.B.

- Follow the (Step 1) - (Step 3) of item 5.1.



- Check the operation P.C.B. as shown below.



5.3. Checking for the main P.C.B.

- Follow the (Step 1) - (Step 3) of item 5.1.





- Check the main P.C.B. as shown below.


(Step 4)
Turn the rear panel, power supply P.C.B. and main P.C.B., and then put on the them to front panel ass'y.
Main P.C.B.
GND plate
NOTE:
Insulate main P.C.B. with insulation material to avoid short-circuit.
(Step 5)
Connect the lead wire.

5.4. Replacement for the power IC

- Follow the (Step 1) - (Step 3) of item 5.1.

- Follow the (Step 1) - (Step 3) of item 5.3.



6. To Supply Power Source and Signal Check

To operate this unit SE-HD550 normally, it is necessary to connect to the unit ST-HD550. When operating the unit SE-HD550, be sure to connect to the unit ST-HD550 by connection cable.

1. Connect with the Tuner (ST-HD550). Refer to Fig. 6-1.

2. Connect the AC power supply cord to the Amplifier / (SE-HD550). Refer to Fig. 6-1.
3. Connect the speakers to speaker terminal. / Refer to Fig. 6-1.
4. Turn on the power of the Amplifier (SE-HD550).
5. Set INPUT SELECTER to select the external source (EXT) of the Amplifier (SE-HD550).
6. Input a sound signal to external input terminal of the Tuner (ST-HD550), and confirm to be outputted from the speaker. (Both High and Low.)

Fig. 6-1.



7. Schematic Diagram Notes

- This schematic diagram may be modified at any time with the development of new technology.

Notes:

S501:

Power standby/on switch (/I)

S503:

Bass down switch (BASS)

S504:

Bass up switch (BASS ▲)

S505:

VGCA (variable gain control amplifier) switch (VGCA)

S506:

Treble down switch (TREBLE ▼)

S507:

Treble up switch (TREBLE ▲)

VR501:

Input selector VR (INPUT SELECTOR)

VR502:

Volume control VR (VOLUME)

- Indicated voltage values are the standard values for the unit measured by the DC electronic circuit tester (high-impedance) with the chassis taken as standard. Therefore, there may exist some errors in the voltage values, depending on theinternal impedance of the DC circuit tester.

No mark

: Power ON

- Important safety notice:

Components identified by ⚠ mark have special characteristics important for safety.

Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.

When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.

- The supply part number is described alone in the replacement parts list.

- Caution!

IC and LSI are sensitive to static electricity.
Secondary trouble can be prevented by taking care during repair.
Cover the parts boxes made of plastics with aluminum foil.
Ground the soldering iron.
Put a conductive mat on the work table.
Do not touch the legs of IC or LSI with the fingers directly.

- Voltage and signal line



: Positive voltage line

: Negative voltage line



: Audio signal line

8. Schematic Diagram

9. Printed Circuit Board Diagram

10. Type Illustration of ICs, Transistors and Diodes

11. Wiring Connection Diagram

12. Block Diagram

13. Replacement Parts List

Notes:

- Important safety notice:

Components identified by ⚠ mark have special characteristics important for safety.
Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used.

When replacing any of components, be sure to use only manufacture's specified parts shown in the parts list.

- The <IA> marks in Remarks indicate language of instruction manual.

<IA>: English

- The marking [RTL] indicates that Retention Time is Limited for this item. After the discontinuation of this assembly in production, the item will continue to be available for a specific period of time. The retention period of availability is dependenton the type of assembly, and in accordance with the laws governing part and product retention. After the end of this period, the assembly will no longer be available.

- All parts are supplied by MESA.

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
1	RHD30082-K	SCREW	4	
2	RGK1324-M	SIDE PANEL(L)	1	
3	RGK1325-M	SIDE PANEL(R)	1	
4	RMZ0339	ZNR COVER	1	
5	RKA0114-K	FOOT	4	
5-1	RKA0083-K	CUSHION	4	
6	XTB3+5JFZ	SCREW	4	
7	RGG0186-S	FRONT PANEL	1	
8	RGL0531-Q	INDICATOR,VGCA	1	
9	RGL0541-Q	INDICATOR,STANDBY	1	
10	RGP0838-S	SUB PANEL	1	
11	RGU1936-S	BUTTON,POWER	1	
12	RGW0357-S	KNOB,VOLUME	1	
13	RGW0362-S	KNOB,SELECTOR	1	
14	RHD26016	SCREW	1	
15	RHN90001	NUT	2	
16	XTBS26+8J	SCREW	4	
17	XTBS3+8JFZ1	SCREW	9	
18	RGN1995C-K	NAME PLATE	1	
19	XTB3+20JFZ	SCREW	4	
20	XTB3+8JFZ	SCREW	2	
21	XTW3+15T	SCREW	2	
22	RKM0412C-N	CABINET	1	
23	XTB3+6JFZ	SCREW	4	
25	RGK1328-S	SIDE ORNAMENT(L)	1	
26	RGK1329-S	SIDE ORNAMENT(R)	1	
27	RGK1332-N	VOLUME ORNAMENT	2	
28	RKW0628-Q	FL WINDOW	1	
29	RKW0630-W	VGCA SHEET	1	
30	REE1087	FFC	1	
A1	EUR7702010	REMOTE CONTROLLER	1	
A1-1	UR64EC2337E	BATT.COVER	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
A2	REE1057	SPEAKER CORD	2	
A3	REE0853	SPEAKER CORD	2	
A4	RSA0006-J	FM INDOOR ANTENNA	1	
A5	RSA0033B	AM LOOP ANTENNA	1	
A6	RJA0035-X	AC POWER SUPPLY / CORD	1	⚠
A7	RQT5744-B	INSTRUCTION MANUAL	1	<IA>
A8	RQCB0169	SERVICE CENTER LIST	1	
C105,06	ECBT1H470J5	50V 47P	2	F1D1H470A006
C107-10	ECBT1H473KB5	50V 0.047U	4	
C111,12	ECBT1H102KB5	50V 1000P	2	F1D1H102A012
C119,20	ECBT1H470J5	50V 47P	2	F1D1H470A006
C123,24	ECBT1H104ZF5	50V 0.1U	2	F1E1H104A001
C125,26	ECBT1H102KB5	50V 1000P	2	F1D1H102A012
C127,28	ECBT1H473KB5	50V 0.047U	2	
C129	ECA1CM331	330U	1	⚠
C130,31	ECBT1H105ZF5	50V 1U	2	F1E1H105A001
C132	ECA1EAK100XB	25V 10U	1	
C133,34	ECBT1H223KB5	50V 0.022U	2	F1D1H223A012
C135,36	ECA0JAK101XB	6.3V 100U	2	
C137-40	ECBT1H473KB5	50V 0.047U	4	
C141	ECBT1H471KB5	50V 470P	1	F1D1H471A012
C142	ECA1HAM470XB	50V 47U	1	
C143	ECKR2H102ZF5	500V 1000P	1	
C149,50	ECBT1H223KB5	50V 0.022U	2	F1D1H223A012
C151-54	ECBT1H821KB5	50V 820P	4	F1D1H821A012
C155,56	ECBT1H104ZF5	50V 0.1U	2	F1E1H104A001
C183,84	ECA1CAK100XB	16V 10U	2	
C187,88	ECA1CAK330XB	16V 33U	2	
C189	ECBT1H104KB5	50V 0.1U	1	
C190	RCE0JKA470BG	6.3V 47U	1	F2A0J470A014
C199	ECBT1C222KR5	16V 2200P	1	
C201	ECA1CAK100XB	16V 10U	1	
C301	ECA1EAK4R7XB	25V 4.7U	1	
C302	ECBT1H103KB5	50V 0.01U	1	
C303	ECA1EAM101XB	25V 100U	1	
C304	ECA1HM101	100U	1	⚠
C305	ECA1EAM101XB	100U	1	⚠
C308	ECA1EM222	2200U	1	⚠
C309	RCE1EM471BV	25V 470U	1	
C311	ECKR1H103ZF5	50V 0.01U	1	F1B1H1030001
C312,13	ECBT1H103KB5	50V 0.01U	2	
C314	ECBT1H104KB5	50V 0.1U	1	
C315	ECBT1H103KB5	50V 0.01U	1	
C316	ECBT1H104ZF5	50V 0.1U	1	F1E1H104A001
C317	ECA1VM101	35V 100U	1	
C319	ECA1EAM331XB	330U	1	⚠
C321	RCE1VKA100BG	35V 10U	1	F2A1V1000011
C322	ECBT1H103KB5	50V 0.01U	1	
C323	ECA2AM100	10U	1	⚠
C324,25	ECA1HAM470XB	47U	2	⚠
C326,27	ECBT1H101KB5	50V 100P	2	F1D1H101A012
C328	ECBT1H104ZF5	50V 0.1U	1	F1E1H104A001

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
C329	ECA1EAM101XB	100U	1	⚠
C331-34	ECBT1H102KB5	50V 1000P	4	F1D1H102A012
C335,36	ECBT1H101KB5	50V 100P	2	F1D1H101A012
C337,38	ECBT1H150JC5	50V 15P	2	
C339,40	ECBT1H331KB5	50V 330P	2	F1D1H331A012
C341,42	ECBT1H103KB5	50V 0.01U	2	
C343,44	ECA1CAK100XB	16V 10U	2	
C345	ECBT1H103KB5	50V 0.01U	1	
C346,47	ECA1EAK100XB	25V 10U	2	
C348	ECBT1H103KB5	50V 0.01U	1	
C349,50	ECBT1H101KB5	50V 100P	2	F1D1H101A012
C351,52	ECBT1C152KR5	16V 1500P	2	
C353,54	ECBT1H103KB5	50V 0.01U	2	
C355,56	ECBT1C392KR5	16V 3900P	2	F1D1C392A010
C357,58	ECA1EAK100XB	25V 10U	2	
C359,60	ECEA1HKAR22B	50V 0.22U	2	
C361,62	ECA1EAK100XB	25V 10U	2	
C391	ECBT1H104ZF5	50V 0.1U	1	F1E1H104A001
C501,02	ECBT1H103KB5	50V 0.01U	2	
C503-06	ECBT1H101KB5	50V 100P	4	F1D1H101A012
C507,08	ECBT1H331KB5	50V 330P	2	F1D1H331A012
C509,10	ECBT1H103KB5	50V 0.01U	2	
C511,12	ECA1EAK4R7XB	25V 4.7U	2	
C513,14	ECA1HAK010XI	50V 1U	2	ECA1HAK010XB
C515,16	ECBT1H473ZF5	50V 0.047U	2	
C517	ECA0JAK221XB	6.3V 220U	1	
C520,21	ECA1HAK010XI	50V 1U	2	ECA1HAK010XB
C601,02	ECA1EAM472XE	4700U	2	⚠
C603	ECQE1104KF3	100V 0.1U	1	
CN110	RJU100W07	CONNECTOR(7P)	1	K1KB07A00018
CN112	RJU100W07	CONNECTOR(7P)	1	K1KB07A00018
CN202	SJS305-1	CONNECTOR(3P)	1	
CN401-08	RJS1A1101T1	CONNECTOR(1P)	8	
CN501	RJS1A6214-1	CONNECTOR(14P)	1	K1MN14C00002
CN601	RJS1A6604T1	CONNECTOR(4P)	1	K1MP04A00008
CP108	RJS9T6ZA	CONNECTOR(9P)	1	K1MP09B00005
CP110	RJT100W07	CONNECTOR(7P)	1	K1KA07A00082
CP112	RJT100W07	CONNECTOR(7P)	1	K1KA07A00082
CP201	RJP1A4204-1	CONNECTOR(4P)	1	K1KA03A00143
CP501	RJS1A6714-Q	CONNECTOR(14P)	1	K1MN14B00054
D101-04	RL1N4003N02	DIODE	4	⚠
D105-07	MA165	DIODE	3	MA2C165
D108	RL1N4003N02	DIODE	1	
D109	MA4051M	DIODE	1	MAZ40510M
D110	MA4150M	DIODE	1	MAZ41500M
D119,20	MA165	DIODE	2	MA2C165
D303	MA4160M	DIODE	1	MAZ41600M / ⚠
D304	1N5402BF	DIODE	1	⚠
D305,06	RL1N4003N02	DIODE	2	⚠
D307	1N5402BF	DIODE	1	⚠

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
D308-10	RL1N4003N02	DIODE	3	⚠
D312	MA4051M	DIODE	1	MAZ40510M
D313	RL1N4003N02	DIODE	1	⚠
D314	MA4091M	DIODE	1	MAZ40910M
D315	MA4240H	DIODE	1	MAZ42400H / ⚠
D316-22	RL1N4003N02	DIODE	7	⚠
D325,26	MA4075M	DIODE	2	MAZ40750M
D328,29	MA4120M	DIODE	2	MAZ41200M / ⚠
D330,31	MA165	DIODE	2	MA2C165
D501-04	MA165	DIODE	4	MA2C165
D505	SLR-325VC	LED	1	B3AAA0000487
D508,09	SELS5923C	LED	2	B3ADA0000083
D510	SLR-325MC	LED	1	B3ABA0000187
D601-04	1N5402BF	DIODE	4	⚠
F1	XBA2C06TB0	FUSE	1	K5D631BL0003 / ⚠
F2	XBA2C20TB0	FUSE	1	K5D202BL0001 / ⚠
FP401,02	RSFMB70KT-L	FUSE PROTECTOR	2	⚠
FP403,04	RSFMB40KT-L	FUSE PROTECTOR	2	K5G402A00010 / ⚠
IC101	RSN314H41	IC	1	⚠
IC301,02	M5218AFPE3	IC	2	C0ABBB000163
IC501	M5218AFPE3	IC	1	C0ABBB000163
JK101	SJS9236-1	JACK,AC IN	1	K2AA2B000002 / ⚠
JK102,03	K4BC04B00029	JACK,SPEAKERS	2	
JK501	RJJ37TN01-2C	JACK,PHONES	1	K2HC103B0106
L101	RLQZ371	COIL	1	ELF15N035AN
L103-06	RLQYR73MW1-0	COIL	4	G0ZZ00001606
P1	RPG5244	PACKING CASE(SE,RS)	2	
P1	RPG5245	PACKING CASE(ST,SL)	2	
P2	RPN1388	PAD(SE)	1	
P2	RPN1389	PAD(ST,SL)	2	
P2	RPN1390	PAD(RS)	1	
P3	SPP740-1	PROTECTION BAG	1	
P4	RPG5250	PACKING CASE / (SYSTEM)	1	
P5	RPQ1142	SPACER	1	
P6	RPF0139-1	PROTECTION BAG / (F.B.)	1	
PCB1	REP3125A-M	P.C.B. ASS'Y	1	[RTL]
PCB2	REP3126A-S	P.C.B. ASS'Y	1	[RTL]
PT102	RTP1H3E001	POWER TRANSFORMER	1	⚠
PT701	RTP2M5B022	POWER TRANSFORMER	1	⚠
Q105	2SA1309ATA	TRANSISTOR	1	2SA1309AWA
Q106,07	2SC3311ATA	TRANSISTOR	2	2SC3311A0A
Q113	2SA1309ATA	TRANSISTOR	1	2SA1309AWA
Q114,15	2SC3311ATA	TRANSISTOR	2	2SC3311A0A

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
Q117,18	2SC3311ATA	TRANSISTOR	2	2SC3311A0A
Q126	UN4211	TRANSISTOR	1	UNR4211
Q127	2SC3311ATA	TRANSISTOR	1	2SC3311A0A
Q301	2SC3940AQSTA	TRANSISTOR	1	2SC3940ARA / ⚠
Q307	2SC3311ATA	TRANSISTOR	1	2SC3311A0A
Q308	2SB621A-R	TRANSISTOR	1	2SB0621AH / ⚠
Q311	2SC3311ATA	TRANSISTOR	1	2SC3311A0A
Q312	2SD592AR	TRANSISTOR	1	2SD0592AR / ⚠
Q313	2SB621A-R	TRANSISTOR	1	2SB0621AH / ⚠
Q317	UN4211	TRANSISTOR	1	UNR4211
Q318	UN4111	TRANSISTOR	1	UNR4111
Q319	2SC3311ATA	TRANSISTOR	1	2SC3311A0A
Q320	UN4211	TRANSISTOR	1	UNR4211
Q501-04	2SC3327A	TRANSISTOR	4	
Q505	UN4111	TRANSISTOR	1	UNR4111
Q506	UN4115	TRANSISTOR	1	UNR4115
R111	ERD2FCG100	10	1	⚠
R112	ERDS2FJ102	1/4W 1K	1	
R113,14	ERDS2FJ182	1/4W 1.8K	2	
R115,16	ERDS2FJ273	1/4W 27K	2	
R117,18	ERDS2FJ100	10	2	⚠
R119,20	ERDS1FJ100	10	2	⚠
R121	ERDS2FJ823	1/4W 82K	1	
R122	ERDS2FJ124	1/4W 120K	1	
R123,24	ERDS2FJ473	1/4W 47K	2	
R137,38	ERDS2FJ182	1/4W 1.8K	2	
R139,40	ERDS2FJ473	1/4W 47K	2	
R143,44	ERDS2FJ100	10	2	⚠
R147,48	ERDS1FJ100	10	2	⚠
R151	ERDS2FJ823	1/4W 82K	1	
R152	ERDS2FJ124	1/4W 120K	1	
R153,54	ERDS2FJ102	1/4W 1K	2	
R155	ERDS1FJ471	470	1	⚠
R156	ERDS2FJ563	1/4W 56K	1	
R157	ERDS2FJ564	1/4W 560K	1	
R158	ERDS2FJ563	1/4W 56K	1	
R159	ERDS2FJ564	1/4W 560K	1	
R160,61	ERDS2FJ223	1/4W 22K	2	
R162	ERDS2FJ103	1/4W 10K	1	
R163	ERDS2FJ473	1/4W 47K	1	
R164	ERDS2FJ332	1/4W 3.3K	1	
R165	ERDS2FJ104	1/4W 100K	1	
R166	ERDS2FJ223	1/4W 22K	1	
R173,74	ERDS2FJ562	1/4W 5.6K	2	
R176-79	ERDS2FJ182	1/4W 1.8K	4	
R180	ERDS2FJ103	1/4W 10K	1	
R181	ERDS2FJ1R0	1	1	⚠
R187,88	ERDS2FJ103	1/4W 10K	2	
R189,90	ERDS2FJ102	1/4W 1K	2	
R213	ERD2FCG100	10	1	⚠
R301	ERDS2FJ392	1/4W 3.9K	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
R306	ERDS2FJ473	1/4W 47K	1	
R307	ERDS2FJ103	1/4W 10K	1	
R309	ERDS2FJ331	1/4W 330	1	
R310	ERDS2FJ681	1/4W 680	1	
R311	ERDS1FJ3R3	3.3	1	⚠
R313	ERDS2FJ473	1/4W 47K	1	
R314	ERDS2FJ392	1/4W 3.9K	1	
R316	ERDS2FJ102	1/4W 1K	1	
R317	ERDS2FJ472	1/4W 4.7K	1	
R318	ERDS2FJ100	10	1	⚠
R319	ERDS2FJ101	1/4W 100	1	
R321	ERDS2FJ103	1/4W 10K	1	
R323,24	ERDS2FJ822	1/4W 8.2K	2	
R325,26	ERDS2FJ102	1/4W 1K	2	
R327,28	ERDS2FJ823	1/4W 82K	2	
R329,30	ERDS2FJ102	1/4W 1K	2	
R331	ERD2FCG100	10	1	⚠
R337,38	ERDS2FJ331	1/4W 330	2	
R341	ERD2FCG100	10	1	⚠
R343,44	ERDS2FJ102	1/4W 1K	2	
R345	ERD2FCG100	10	1	⚠
R347,48	ERDS2FJ103	1/4W 10K	2	
R349,50	ERDS2FJ104	1/4W 100K	2	
R353-56	ERDS2FJ103	1/4W 10K	4	
R361,62	ERDS2FJ102	1/4W 1K	2	
R364,65	ERDS2FJ560	1/4W 56	2	
R366	ERDS2FJ103	1/4W 10K	1	
R501-04	ERDS2FJ470	1/4W 47	4	
R505,06	ERDS2FJ153	1/4W 15K	2	
R507,08	ERDS2FJ332	1/4W 3.3K	2	
R509,10	ERDS2FJ223	1/4W 22K	2	
R511-14	ERDS2FJ102	1/4W 1K	4	
R515,16	ERDS2FJ223	1/4W 22K	2	
R517	ERDS2FJ561	1/4W 560	1	
R519,20	ERDS2FJ102	1/4W 1K	2	
R521	ERDS2FJ821	1/4W 820	1	
R523	ERDS2FJ102	1/4W 1K	1	
R524	ERDS2FJ153	1/4W 15K	1	
R525	ERDS2FJ103	1/4W 10K	1	
R526	ERDS2FJ102	1/4W 1K	1	
R527	ERDS2FJ222	1/4W 2.2K	1	
R528,29	ERDS2FJ472	1/4W 4.7K	2	
R530	ERDS2FJ153	1/4W 15K	1	
R531	ERDS2FJ103	1/4W 10K	1	
R532	ERDS2FJ122	1/4W 1.2K	1	
R533	ERDS2FJ152	1/4W 1.5K	1	
R534	ERDS2FJ182	1/4W 1.8K	1	
R535	ERDS2FJ471	1/4W 470	1	
R538	ERDS2FJ474	1/4W 470K	1	
R539	ERDS2FJ154	1/4W 150K	1	
RL101	RSY0040M-0	RELAY	1	⚠

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
S501	EVQ11G05R	SW,POWER	1	
S503-07	EVQ11G05R	SW,PUSH	5	
VR501	K9AA012A0003	V.R.,INPUT SELECTOR	1	
VR502	EVEKC2F2524B	V.R.,VOLUME	1	
W301	REX0962	FLAT CABLE(20P)	1	
Z101	ERZV10V511CS	COMPONENT / COMBINATION	1	

14. Cabinet Parts Location



15. Packaging



F010400000YM/KH


A POWER SUPPLY CIRCUIT
:POSITIVE VOLTAGE LINE
:NEGATIVE VOLTAGE LINE
:AUDIO SIGNAL LINE
W301
Lch IN
A.GND
Rch IN
MUTE
POWER
+B(13V)
LED CONT
CT
D.GND
-B(-13V)
+B(16V)
+B(12V)
KEY SE
JOG A
JOG B
HPDET
-B(-24V)
FL1
FL2
SYNC
To TUNER
(ST-HD550)
E201
R321 10K
R213 10
Q319
2SC3311ATA
LED DRIVE
15.3V
10.4V
11V
Q318
UN4111TA
LED DRIVE
15.3V
11V
0V
R316 1K
C315 0.01
C316 0.1
C314 0.1
D314 MA4091MTA
Q320
UN4211TA
SWITCHING
(HP DET.)
5.4V
0.2V
R361 1K
C327 100P
C326 100P
R362 1K
4.2V
Q317
UN4211TA
LED DRIVE
14.8V
CP501
B OPERATION CIRCUIT
CN501
VR502
EVEKC2F2524B
(VOLUME)
VR501
K9AA012A0003
(INPUT SELECTOR)
D505
SLR-325VC
D510
SLR-325MC
(VGCA)
R535 470
R525 10K
R524 15K
R531 10K
R530 15K
S501
S503 (BASS ▼)
S504 (BASS ▲)
S505 (VGCA)
S506 (TREBLE ▼)
S507 (TREBLE ▲)
R521 820
R523 1K
R532 1.2K
R533 1.5K
R534 1.8K
D503 MA165TA
D504 MA165TA
R519 1K
R520 1K
R538 470K
C521 50V1
R529 4.7K
Q505
UN4111TA
MUTING CONT.
D508,509
SELS5923C
(ILLUMINATION)
Q506
UN4115TA
MUTING CONT.
1V
1.3V
R526 1K
R528 4.7K
R517 560
D508
D509
C520 50V1
R539 150K
R527 2.2K
C517 6.3V220
C509 0.01
C511 25V4.7
R505 15K
R507 3.3K
D501 MA165TA
D502 MA165TA
IC501
M5218AFPE3
HEADPHONES AMP
R501 47
R503 47
C503 100P
C505 100P
R515 22K
C513 50V1
R513 1K
Q501
C501 0.01
R511 1K
Q503
C507 330P
R509 22K
R514 1K
Q502
C502 0.01
Q504
R512 1K
C508 330P
R510 22K
JK501
PHONES
R502 47
R504 47
C504 100P
C506 100P
R516 22K
C514 50V1
C516 0.047
Q501,502
2SD2144STA
MUTING
C515 0.047
R506 15K
R508 3.3K
C510 0.01
C512 25V4.7
Q503,504
2SD2144STA
MUTING

:POSITIVE VOLTAGE LINE :NEGATIVE VOLTAGE LINE :AUDIO SIGNAL LINE




C MAIN CIRCUIT
:POSITIVE VOLTAGE LINE
:NEGATIVE VOLTAGE LINE
:AUDIO SIGNAL LINE
IC101
RSN314H41
POWER AMP
HF Rch
HF Lch
LF Rch
LF Lch
+IN(GND)
GND
—VM
AC IN
—Vcc
+Vcc
0V
-12.3V
-21V
21V
CP110
CP109
CP106
L105 0.7 μH
L106 0.7 μH
L103 0.7 μH
L104 0.7 μH
R143 10
R144 10
R117 10
R118 10
R111 10
R155 470
C151 820P
C119 47P
C154 820P
C153 820P
C152 820P
C139 47K
C190 6.3V47
R189 1K
C189 0.1
C141 470P
R123 47K
D110 MA4150MTA
C132 25V10
C149 0.022
C105 47P
C150 0.022
R124 47K
R140 47K
C120 47P
R115 27K
C106 47P
R113 1.8K
R138 1.8K
R137 1.8K
R174 5.6K
R114 1.8K
R116 27K
R173 5.6K
R326 1K
R325 1K
R178 1.8K
R179 1.8K
R176 1.8K
R177 1.8K
D602 1N5402BM21
D601 1N5402BM21
D604 1N5402BM21
D603 1N5402BM21
C601 4700
C602 4700
C131 1
C130 1
C603 0.1
W108
W601
CP108
CN601
FP401 RSFMB70KT-L
FP402 RSFMB70KT-L
FP403 RSFMB40KT-L
FP404 RSFMB40KT-L
AC16V
AC12.6V
AC3.8V
CN401
CN402
CN403
CN404
CN405
CN406
CN407
CN408
PT701
CN202
D104
D101-104 RL1N4003N02
D103
D101
D102
D107 MA165TA
C129 330
RL101
D106 MA165TA
D105 MA165TA
R154 1K
R153 1K
PT102
AC 10.5V
CP201
D POWER TRANSFORMER (1) CIRCUIT
E POWER TRANSFORMER(2) CIRCUIT

⇨:AUDIO SIGNAL LINE



M5218AFPE3



RSN314H41



2SB621AQRSTA
2SD592AQRSTA





2SA1309ATA
2SC3311ATA
UN4111TA
UN4115TA
UN4211TA

2SC3940AQSTA



2SD2144STA



MA165TA



MA4051MTA





MA4075MTA
MA4091MTA
MA4120MTA
MA4150MTA
MA4160MTA
MA4240MTA

1N5402BM21
RL1N4003N02



SELS5923C
SLR-325MC
SLR-325VC


SPEAKERS
C MAIN P.C.B.
CP106
CP110
CP109
CN106
CN110
CN109
CP112
W601
W108
W301
To TUNER
A POWER SUPPLY P.C.B.
CP108
D POWER TRANSFORMER (1) P.C.B.
CP501
PT701 (POWER TRANSFORMER)
CP201
CN601
PT102 (POWER TRANS-FORMER)
E POWER TRANSFORMER (2) P.C.B.
CN501
B OPERATION P.C.B.
CN112
BROWN
BLUE
F AC IN P.C.B.
AC IN

A



A Amplifier

⑨ **Input selector (INPUT SELECTOR)**
⑩ **VGCA indicator (VGCA)**
⑪ **Volume control (VOLUME)**
⑫ **Standby indicator**
When the unit is connected to the AC mains supply, this indicator lights up in standby mode and goes out when the unit is turned on.
⑬ **Standby/on switch (⏻/I)**
Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.
⑭ **Bass buttons (BASS ▲, ▼)**
⑮ **Treble buttons (TREBLE ▲, ▼)**
⑯ **VGCA (variable gain control amplifier) button (VGCA)**
⑰ **Headphone jack (PHONES)**

B



B Remote control

Buttons ❷, ❸, ❶❶, ❶❸, and ❷❶ function in the same way as the controls on the main unit.

㊳ **Sleep timer button (SLEEP)**
㊴ **Numbered buttons**
㊵ **Play mode button (PLAY MODE)**
㊶ **Muting button (MUTING)**
㊷ **Cancel button (CANCEL)**
㊸ **FM mode button (AUTO/MONO)**
㊹ **Input select buttons (CD, TAPE, EXT, TUNER)**
㊺ **Basic operating buttons**
Function changes according to the source.


NOTES ● ⇨: AUDIO SIGNAL LINE
● ( ) indicates pin No. Right channel.
N F
M5218AFPE3
IC301
BUFFER AMP
+B2
-B2
10 (11)
12
3
-Vcc
8
-VM
2
+Vcc
-B1
+B1
MUTING
SHORT DET.
POWER ON/OFF
BIAS
7 (5)
6
9
4 (1)
RSN314H41
IC101
POWER AMP
SPEAKERS (LF) (6 Ω)
SPEAKERS (HF) (6 Ω)
M5218AFPE3
IC302
13 (14)
N F
Q118,120, 126,127
SWITCH-ING
D331
PROTECTOR/ OVER LOAD DET.
Q105~107, 113~115,117
D108,109
KEY SWITCH (S501,503~507)
M5218AFPE3
IC501
HEADPHONES AMP
PHONES
Q503 (Q504)
Q501 (Q502)
MUTING
Q506
Q505
MUTING CONT.
D502
D501
D504
D503
Q320
HP DET
W301
Lch IN
A.GND
Rch IN
R ch
MUTE
POWER
+B(13V)
LED CNT
CT
D.GND
-B(13V)
+B(16V)
+B(8V)
KEY SE
JOG A
JOG B
HPDET
-B(24V)
FL1
FL2
SYNC
To TUNER BLOCK DIAGRAM
Q312
REGULATOR
Q313
D601~604
PT701
POWER TRANSFORMER
Q307
RELAY DRIVE
RL101
F1
Z101
L101
F2
AC IN
D308,309
Q301
D303,310,322
REGULATOR
Q317~319
LED DRIVE
D510 (VGCA)
D304~307
Q311
LED DRIVE
D505 (⏻/ I)
Q308
D315~317
REGULATOR
D318~320
D313
D101~104
PT102
POWER TRANSFORMER
D105
D106
VR502 (VOLUME)
VR501 (INPUT SELECTOR)


A
B
C
D
E
F
1
2
3
4
5
6
7
8
A POWER SUPPLY P.C.B.
To TUNER
CN106
CN110
CN109
E201
W301
Q301
Q307
Q308
Q311
Q320
Q318
Q319
Q317
Q313
Q312
IC301
IC302
CP501
R213
2296AB
(REP3125A-M)

B OPERATION P.C.B.



(REP3126A-S)

C MAIN P.C.B.



(REP3125A-M)


A
B
C
D
E
F
1
2
3
4
5
6
7
8
D POWER TRANSFORMER(1) P.C.B.
FP404
CP108
9 8 7 6 5 4 3 2 1
FP403
FP402
FP401
CN408 CN407 CN406 CN405 CN404 CN403 CN402 CN401
2296AE
(REP3125A-M)
PT701
(POWER
TRANSFORMER)
E POWER TRANSFORMER(2) P.C.B.
C129
D104
D102
D103
D101
D107
CN202
RL101
PT102
(POWER
TRANSFORMER)
CP201
CN601
D105
D106
R153
R154
2296AD
(REP3125A-M)
F AC IN P.C.B.
AC IN
(230-240V 50Hz)
JK101
F2 T2A
FC4
FC3
L101
F1 T630mA
FC1
FC2
Z101
2296AC
(REP3125A-M)
CN112
7 6 5 4 3 2 1